

- → Perfect for small applications
- → 300 OR 400 watt AC, DC or combination input
- → **120 OR 277 volt input**
- → Alternative to wall packs
- $\rightarrow \,$  Light up fluorescent indoor and 12V remote lights with same system



- → Perfect for small applications
- → 500-2000VA
- → 120 OR 277 volt input
- → Self-testing, self-diagnostics, alarms and event logs
- → Small, compact footprint
- → 98% efficient



- → Perfect for medium applications... retail, schools, etc.
- → 1500-16,700 VA, 98% efficient!
- → All voltage configurations available
- → Central power system, for one time testing
- → Self-testing, self-diagnostics, alarms and event logs



- → Perfect for small to large, THREE PHASE applications
- → 4800-50,000 VA, 98% efficient!
- → All voltage configurations available
- → Central power system, for one time testing
- → Self-testing, self-diagnostics, alarms and event logs